

PART #	DESCRIPTION
1760 JT	Shaft for Delivery Table
1769 JT	6' Delivery Table Belt
1782 JT	8' Delivery Table Belt
1783 JT	Table Mounting Bracket
3861 JT	Gear for Water Meter Roller
3862 JT	Chrome Roller Gear
3863 JT	Gear
3864 JT	Gear for Water Motor
3869 JT	Washer
3870 JT	Bearing Block Chrome Roller
3871 JT	Block for Water Metering Roller
3873 JT	Stud
3874 JT	Terminal for Dampener Tie Rod Assembly
3876 JT	Tie Rod
3895 JT	Water Metering Roller - Litho Roll Hard
3895 JT	Water Metering Roller - Litho Roller Soft
3895 JT	Water Metering Roller - Jomac Roller
3896 JT	Water Form Roller - Litho Roll - Hard
3896 JT	Water Form Roller- Litho Roller - Soft
3896 JT	Water Form Roller - Jomac
3896 JT	Roller Kit - 7 Rollers - Litho Roller - Soft
3896 JT	Roller Kit - 7 Rollers - Litho Roller - Hard
3896 JT	Roller Kit - 7 Rollers - Litho Roller - Hard
3991 JT	Arm-Stripper Assembly Gear Side
3992 JT	Stripper Bar
3993 JT	Stripper Plate
3994 JT	Arm
3995 JT	Deflector
3997 JT	Stripper Blade
4049 JT	Washer for Vibrator Plate
4077 JT	Rod Impression Adjustment Assy
4078 JT	Plate
4079 JT	Plate for Double Solenoid
4100 JT	Gear
4112 JT	Tie Bar
4117 JT	Spacer
4147 JT	Roller Shaft
4260 JT	Solenoid Plate
4285 JT	Retainer for P/C Bearing
4309 JT	Skew Bar Old Style 3" P/C
4310 JT	Clamp for Skew Bars
4316 JT	Gear for Lower Entrance Roller Shaft
4329 JT	Pic Screw for Old Style Dog / Flange Assembly
4399 JT	Lower Entrance Roller
4406 JT	Single Solenoid Mounting Bracket
4408 JT	Solenoid Pin
4409 JT	Tie bar
4415 JT	See 44259 R.H. / 44260 L.H. Terminal
4416 JT	Pin
4437 JT	Key .187 X .187 X 1-5/8
4444 JT	Plate

4445 JT Key .125 X .125 X 3/4
4446 JT Spacer for Vibrator Gear Box Assy
4451 JT Copper Distributor Roller
4452 JT Hub - See 42261
4454 JT K.O. Shaft
4455 JT Key
4458 JT Copper Roller
4459 JT Oscillating Roller Shaft
4460 JT Key
4461 JT Key
4477 JT Lever
4478 JT Arm
4480 JT Link
4490 JT Gear Idler
4491 JT Stud for Idler Roller
4494 JT Bush Plate for Jet Press Plate Cylinder Assembly
4505 JT Plate, Guide OP Side
4506 JT Plate, Guide GS
4507 JT Plate, Guide OP Side
4508 JT Plate, Guide Gear Side
4509 JT Plate Guide Wide
4510 JT Plate, Guide Thin
4511 JT Guide - Stainless
4512 JT Guide - Stainless O.S. Middle Aligner Section Hold Down
4513 JT Guide - Stainless G.S. For Micro Switch block
4518 JT Gear for Copper Distributor Roller
4519 JT Spacer for Ink Form Roller
4521 JT Spring for Impression Adjustment Assy.
4523 JT Brake
4527 JT Spacer
4530 JT Harmonic Drive
4532 JT Felt Oil Pad
4535 JT Oiler, Harmonic
4550 JT Stud Cover
4587 JT Cams
4589 JT Eccentric
4591 JT Gear Box
4593 JT Space for Ink Idler Rollers
4594 JT Vibrator Gear Box Plate
4595 JT Worm Gear
4596 JT Ink Fountain Locking Springs
4597 JT Rail
4598 JT Latch for Ink Fountain Lock Down
4622 JT Delivery Table Support Shaft
4627 JT Clamp for Impression Adjustment Plate
4634 JT Chain for Aligner Adjustment
4635 JT Guide - Stainless O.S. & G.S. Outside Adjustable Guide
4636 JT Collar for Blanket Cylinder
4639 JT Pin for Retaining Form Arm Springs
4640 JT Clamp K.O.
4641 JT K.O. Spring
4664 JT Vibrator Plate

4668 JT Ink Fountain Blade
4677 JT Screw Eye
4680 JT Base, Ink Fountain
4686 JT Bar for Ink Fountain
4688 JT Ink Fountain Key
4690 JT Stud for Impression Adjustment Assembly
4757 JT Spacer
4758 JT Roller
4902 JT Blank Plate
4905 JT Link for Impression Arm Only One Required
5096 JT Pulley
5316 JT Lincoln Grease Fitting
6004 JT Rear Aligner Shaft Dual Feed
6004 JT Rear Aligner Shaft Dual Feed Press Pre-Outboard Drive
6005 JT Washer
6010 JT Gear, Feed Cam
6046 JT Spacer for Feed Cam Shaft Dual Feed Presses
6048 JT Adapter, Housing
7168 JT Collar, Shaft, Sucker
7174 JT Spring Guide Top Feed Self Seal
7175 JT Vacuum Hose for Cast Iron Feed
7443 JT Roller
7446 JT Belt Endless
7449 JT Gear, Spur, Aligner
7452 JT Spacer
7492 JT Pin for Aligner Rail - Ball Nose Spring Loaded
7553 JT Spacer
7561 JT Feed Guide Support / Tie Bar
7576 JT Pusher Slotted
7577 JT Spacer
7578 JT Shaft, Aligner Chain
7580 JT Knob Aligner Section/Plate Bender
7582 JT Shaft for Feed Cam C.I. Feeder
7582 JT Rear Aligner Shaft Top Feed Press Pre-Outboard Drive
7583 JT Rear Aligner Shaft for Top Feed Press
7595 JT Power Drive Shaft - Small
7597 JT Handwheel
7599 JT Block for Feed Belt Take-up Assy
7605 JT Sprocket
7607 JT Shaft for Feed Belt Take-up Assy
7609 JT Pulley
7611 JT Gear
7612 JT Boss, 3' CI
7614 JT Clamp for Feed Cam
7629 JT Shaft C.I. Feed
7629 JT Pulley Shaft for Cast Iron Feed
7631 JT Tube, Sucker Gear Side CI Feed
7632 JT Tube, Sucker OP Side CI Feed
7634 JT Feed Shell
7640 JT Guide Feeder for Cast Iron Feed Top Guide
7642 JT Top Feed Plate C.I. Feed
7643 JT Guide G.S.

7644 JT Block- Cast Iron Feed Plate Support Block
7644 JT Block C.I. Feed plate support
7645 JT Guide - Support Front Guide
7646 JT Support
7648 JT Support - Guide Back
7649 JT Support - Guide Back
7650 JT Plate, Feed Guide
7651 JT Support Bar for Feed Guides
7653 JT Guide for Top Feed Envelope Supports
7653 JT Feed Guide Envelope Support Top Feeder
7654 JT Washer
7661 JT Cover, Feed Cam
7665 JT Support, Bogie Rollers CI Feed
7723 JT Center Rail Support
7729 JT Paul, Setting Pushers
7731 JT Sprocket
7739 JT Tail Lifter
7763 JT Guide O.S.
7764 JT Guide for Gear Side
7774 JT Clamp
7788 JT Arm for Aligner Jam Assy
7789 JT Bracket for Aligner Jam Assy.
7790 JT Plate for Aligner Jam Assy
7900 JT Spacer Cast Iron Feeder Pinch Wheels
7900 JT Spacer for Top Feed Pinch Wheels
7903 JT Washer For Pinch Roller Tension Springs
7903 JT Washer for Top Feed Pinch Roller
7904 JT Screw for C.I. Feed Pinch Wheel Adjustment
7907 JT Pinch Wheel 1/2 wide
7915 JT Bracket - for C I pinch wheel tension screws
8000 JT Mounting Bar, Sucker
8001 JT Spacer for Top Feeder Sucker Bar
8002 JT Guide Support
8005 JT Sprocket - Old Style Top Feed Chain Drive
8028 JT Spring for Feed Belt Take-up O.S.
8029 JT Spring for Feed Belt Take-up G.S.
8034 JT Spacer
8040 JT Pulley
8043 JT Leaf Hold Down
8044 JT Sprocket Feed End
8056 JT Spring Retension
8058 JT Shaft Aligner Jam
8062 JT Spring for Stripper Assembly
8063 JT Plug
8065 JT Plate, Guide LH
8066 JT Plate, Guide RH
8069 JT Bushing Lower Feed Arm "small"
8070 JT Block, Aligner
8073 JT Spring
8074 JT Guide
8075 JT Support Mount for Paper No Paper Switch
8077 JT Spacer for Feed Guide

8089 JT Shaft C.I. Feed Stack Assy
8090 JT Arm for Feed Stack Support Assy. C.I. Feed
8091 JT Support For Feed Stack Support Assy C.I. Feed
8092 JT Spacer for Feed and Imp. Adj. Assy.
8098 JT Spacer for Delivery Table Lolly-pop
8099 JT Bracket for Aligner Guides
8140 JT Cover, Base Feed End
8142 JT Cover, Base OP Side
8152 JT Spacer
8184 JT Squeegee Blade
8212 JT Chain Segment
8213 JT Chain Segment 1/2 link
8245 JT key .187 X .187 X 8"
8247 JT Key 1/4 X 1/4 X 1
8280 JT Key 1/4 X 1/4 X 5
11007 JT Arm, Guide
11011 JT Guide -Top Feed
11014 JT Bogie Roller Shaft for Cast Iron Feed
11018 JT Pulley Shaft for Swing Away feed
11022 JT Top Plate, Sheet Metal Feeder
11023 JT Bar, Sucker Bar Attaching SM Feeder
11024 JT Sucker Tube OP Side
11025 JT Sucker Tube Gear Side
11027 JT Guide
11029 JT Guide, Top Feed
11031 JT Feed Arm with Bushing
11031 JT Feed Arm for Cast Iron Feed ** No Bushing or Cam Follower
11036 JT Disc, Seal
11039 JT 1 Up Cam
11040 JT 2 Up Cam
11119 JT Feed Arm Clamp Top Feed
11129 JT Guide Extension
11130 JT Link Tube
11143 JT Sucker Bar Moly Coated
11181 JT Screw 6-32 X 1/8
14272 JT Ductor Roller
16792 JT Collar
19201 JT Gear, Spur
19202 JT Adapter, Housing
19203 JT Gear - Lower Feed Drive Gear
19207 JT Gear, Spur
19208 JT Gear, Spur
19209 JT Pinch Roller
19211 JT Gear, Spur
19216 JT Gear, Spur, Idler
19217 JT Adapter, Housing, Gear Idler D
19218 JT Lower Feed Pinch Roller Shaft
19220 JT Arm, Idler OP Side
19221 JT Arm, Idler, GS
19226 JT Pin, Grooved, Idler Arm
19232 JT Guide - Back Lower Feed Long
19234 JT Plate for Front Guide Lower Feed

19239 JT Bracket, Mounting Feeder
19240 JT Stud, Clamp Handle
19241 JT Lever, Manual Control
19242 JT Block, Support Document
19243 JT Plate, Document Support Btm Feed
19244 JT Spacer for Pivot Lower Feed Clamp Assy
19255 JT Shaft for Lower Feed
19256 JT Gear for Lower Feed Shell Drive with Hub
19257 JT Arm Sucker Rocker
19258 JT Support Stud for Lower Feed Arm - Small Style
19266 JT Gear, Spur, Sucker
19267 JT Cap, Tube, Roller
19269 JT Cap, Retention
19276 JT Coupling, Clamp
19281 JT Gear, Spur
19284 JT Shaft, Idler Long
19285 JT Shaft, Idler Short
19287 JT Lower Feed Arm "small"
19292 JT Guide for Back Lower Feed Short
19303 JT Lower Plate for Weight Assembly
19312 JT Stud - weight assy 1/4 - 20 thread
19313 JT Paper weight - large 3"
19314 JT Paper weight - medium 2"
19315 JT Paper weight - small 1"
19321 JT Upper Plate for Weight Assembly
19334 JT Gear - Lower Feed Height Adjustment
19335 JT Gear Rack for Lower Feed Hopper Height Adjustment
19336 JT Shaft, Support Guide Wide
19337 JT Plate, End Mounting
19338 JT Stud, Shoulder, Headless
19339 JT Pin, Eccentric
19340 JT Support, Shaft
19341 JT Plate, Support, Lower Feeder
19342 JT Plate, Rack Connector
19345 JT Guide - Lower Feed
19362 JT Guide Block -Lower Feed Spring Guides
19363 JT Guide - Lower Feed Spring Guide
19406 JT Clamp
19463 JT Frame, Side OP
19464 JT Frame, Side GS
21231 JT Fountain Control Box Mounting Plate
21302 JT 3" Plate Cylinder
21347 JT Tie Bar
21409 JT Handle K.O.
21573 JT Spring Guide entrance roller narrow
21656 JT Knob, Handle
21657 JT Washer K.O.
21714 JT Chrome Roller
21736 JT Pivot Arm
22254 JT Exit Roller
22251 JT Plug / Block
22256 JT Exit Roller Shaft

22264 JT Ecentric, Impression 3"
22267 JT 3" Impression cylinder
28040 JT Stud
28282 JT Knob 3" P/C
28396 JT Water Trays
28520 JT Shaft 6" P/C
28544 JT Dampener Brake
28556 JT Arm, Pivot
28599 JT Spring Retainer Super Jet Plate Cylinder
28672 JT Tube Lower Feed Tie Rod
29092 JT Stud
29093 JT Dampener Tray Stud Extension
29094 JT Gear
29095 JT Gear, Water Sys
29106 JT Gib Gear Side
29107 JT Gib OP Side
29113 JT Aligner Sprockets
29177 JT K.O. Wire 6" Ftn #2
29211 JT Block, Bearing
29212 JT Bracket, Mounting
29213 JT Hinge, Plate GS
29214 JT Plate, Hinge OP Side
29217 JT Shaft for Lower Feed Gear Cluster
29218 JT Block - "Spider" Assy Guide
29219 JT Bar for "Spider" Hold Down Assy Guide
29220 JT Spider Assy - Arm Rear G.S. - Rubber Transfer Roller System
29221 JT Spider Assy - Arm Front G.S. - Rubber Transfer Roller System
29235 JT Screw for Chrome Roller Adjustment
29235 JT Adj Screw SQ Head, Water Rollers
29236 JT Washer
29276 JT Plate Mandrel Super Jet
29380 JT 4 Up Cam Super Jet
29404 JT Self Seal Cam
29405 JT Cap, Water Form
29417 JT Lever
29418 JT Stud, Continous Thread
29425 JT Ecentric, Water Form Roller
29442 JT Dog Plate
29443 JT Dog Plate
29453 JT Stud
29464 JT Teflon Shield for Lower Feed Sucker Ports
29514 JT K.O.Screw
29524 JT Guide for Plate Front Guide
29547 JT Spacer
29570 JT Bar, Sucker Wide
29571 JT Spacer Block for Outboard Sucker Bar
29577 JT Sucker 3"
29578 JT Sucker, Outboard OP Side
29579 JT Sucker, Outboard GS
29580 JT Spacer, Sleeve
29581 JT Bracket, Sucker Support
29582 JT Bracket, Sucker Support

29774 JT Support for Paper Weight Assy
29775 JT Plate for Weight Assembly
29776 JT Plate for Weight Assembly
29777 JT Spacer
29778 JT Spacer for Weight Assembly
29779 JT Spacer for Weight Assembly
29784 JT Gear, Spur
29786 JT Key
29790 JT Plate, Mounting, Hopper
29791 JT Feeder, Front Plate OP Side
29792 JT Plate, Mounting, Feeder GS
29798 JT Key
29807 JT Key
29808 JT Key
29939 JT 2 UP Perfector Cam Super Jet
30138 JT Bushing Oscillating Roller
30139 JT Gear Cover-water
30147 JT Bracket, Mounting Spring
30183 JT Drive belt pulley 1/2" belt 3/4 bore 3/16 keyway O D
30215 JT Plate Skew Bar for Super Jet
30252 JT Block OP Side
30253 JT Block
30350 JT Latch Plate
30609 JT Shutter
30663 JT Leaf Guide Pressure Support
30688 JT Shaft for bogie wheels swing away feeder
30689 JT Shaft for bogie wheels swing away feeder
30691 JT Sprocket
30692 JT Shaft
30693 JT Sprocket, SM Feeder Drive Chain
30695 JT Top Feed Belt Pulley
30696 JT Shaft Cross Bar
30699 JT Spacer, Sleeve
30700 JT Arm, Idler Pully
30701 JT Shaft, Idler Pully
30717 JT Stud, Arm cam Follower see 47189
30718 JT Spacer, Ring
30719 JT Hub, Body
30720 JT Shaft, Grooved, Headless
30721 JT Hub Body RH
30722 JT Clamp
30723 JT Shaft - Dual Feed Press Cam see 49099
30724 JT Cap See Hole On Right
30726 JT Gear, Spur Cam
30728 JT Shaft Jam Assy
30729 JT Hanger for Lower Feed Jam Switch
30730 JT Hanger for Lower Feed Jam Switch
30731 JT Feeder Drive Chain Top Feeder
30732 JT Belt - Long
30733 JT Belt - Short
30736 JT Aligner Shaft Adapter for Handle
30738 JT Support, Paper Guide

30741 JT Impeller 2 11/16 Dia
30744 JT Stud, Cam Cover
30771 JT Aligner Spindle Bushing - Gear Side
30772 JT Aligner Spindle bushing - Operator Side
30776 JT Strap - Guide for Swing Away Feed
30809 JT Strap - Guide for Swing Away Feed
30854 JT Air Valve for top to Bottom Feed No Fittings
30863 JT Pin - Shaft for Lower Feed Drive Gear
30870 JT Pin - Shaft for Lower Feed Drive Gear
30871 JT Hub, Body
30872 JT Arm, Bogie Roller Assy
30878 JT Cap See Hole On Left
30879 JT Plate, Main Side Gear Side
30881 JT Blanket Material
30882 JT Vacuum hose
30924 JT Plug Special .125 x .25
30932 JT Shaft for Steel Transfer Wheels
30943 JT Support, Paper Guide
30953 JT Motor Mount Bar - Long
30954 JT Motor Mount Bar - Short
30978 JT Dampener Spring
31009 JT Stud
31023 JT Brake Band
31032 JT Worm
31039 JT Spacer
31040 JT Brake Drum
31041 JT Adapter
31093 JT Helical Spring
31245 JT Water Gib Stud
31971 JT Spider Assy - Arm Front O.S. - Rubber Transfer Roller System
31972 JT Spider Assy - Arm Rear O.S. - Rubber Transfer Roller System
31973 JT Bushing for "Spider" Hold Down Assy Arms 47171 / 47173
31998 JT Bushing
32166 JT Bushing
32223 JT Hinge for Old Style Rear Cover
32224 JT Nut Plate
32364 JT Flange Plate
32749 JT Flange Plate
32763 JT Bolt for Felt Bearer Pad
32766 JT Bracet Oiler system
32769 JT Oil Bracket
32771 JT Stud for Felt Bearer Pad
32774 JT Stud for Felt Bearer Pad
32888 JT Block
32991 JT Block
33015 JT Front Aligner Shaft
33105 JT Front Aligner Shaft - Pre-Outboard Drive - with By-Pass Gearing
33220 JT Nip Guard
33501 JT Water Motor Bracket
33540 JT Motor Bracket
33547 JT Arm,
33602 JT Spacer

33861 JT Spacer
34094 JT Harmonic Drive
34466 JT Pusher Block, Aligner Chain - Used
34509 JT Bogie Wheel Shaft
34510 JT Bogie Wheel Shaft
34608 JT Side Plate CI Feeder OP Side
34609 JT Feed Arm Post C.I. Feed
34612 JT Side Plate CI Feeder Gear Side
34613 JT Shaft for C.I. Feed Belt pulleys
34617 JT Support Piece for Cast Iron Feed Guide
34618 JT Nut Plate for C.I. Feed Guide
34636 JT Bushing for Cast Iron Feed Sucker Bar
34637 JT Guide - Spring steel 3" Press
35012 JT Cover, Chain CI Feeder
35118 JT Guide - Spring steel 3" Press
35120 JT Elbow Top Feed Sucker Assembly
35142 JT Support, Guide
35577 JT Spacer for Stripper Assembly Roller
35590 JT Bar for Swing Away Feed Pinch Roller Tension Screws
35593 JT Spacer - Swing Away Feed 1/4 x 5/8 x 1/4
35866 JT Support for A-7055 Wash-up Handle
35949 JT B/C Gear
35950 JT Gib Blocks
35951 JT Gib Blocks
35954 JT Eccentric
35960 JT Eccentric Imp Adj Assy OP
35964 JT Eccentric
35965 JT Shaft, Imp Handle 3" & 6"
35967 JT Gear Impression Cylinder
35969 JT Imp Cyl Shaft 6"
35970 JT Eccentric, Impression GS SJ
35986 JT Gib Blocks
35989 JT Impression Adjustment Handle
36086 JT Impression Adjustment Handle
36099 JT Cover, Exit Roller Gear
36110 JT Cover, Cam, Inside
36151 JT Sensing Cam
36153 JT Switch Support for Paper Sensing Cam Switch
36154 JT Blanket Cylinder Shaft
36177 JT Cover Stud for 36155 Cover
36180 JT Bracket, Mounting Hinge
36181 JT Bracket, Mounting
36202 JT Table Leg Brace
36388 JT Table Leg Brace
36393 JT Table Leg Brace
36702 JT Hanger, OP Side
36703 JT Gear
36704 JT Stud By pass gearing
36705 JT Gear for 3" Perfect Cylinder
36709 JT Gear for 3" Perfect Cylinder
36710 JT Gear ring
36711 JT Side Frame O.S. Dampener

36714 JT Side Frame OP Side Damp
36716 JT Side Frame Gear Side
36744 JT Busing for 3" Impression Cylinder Anti-backlash Gear
36788 JT Nut Plate for Delivery Table
36878 JT Screw for Dampener Cover
36896 JT Handwheel
36907 JT Guide Clamp
36908 JT Guide
37287 JT Base Cover
38022 JT Cover, Base GS
38334 JT Cover, Access, Sucker
38354 JT Aligner Chain take-up Sprocket
38505 JT Support for Lolly-pop
38506 JT Shaft for Lolly-pop
38507 JT Arm for Lolly-pop
38509 JT Lolly-pop Roller
38510 JT Clamp Screw for Lolly-pop
38511 JT Guide Screw
38541 JT Guide for Swing Away Feed
38898 JT By-pass gear plate Super Jet
38901 JT Side Frame cover HWS
38992 JT 3" Plate Cylinder - Rear Tucking Style
39190 JT 3" Plate Cylinder - Rear Tucking Style
39195 JT Plate Mandrel Deep Tuck
39234 JT Delivery Table Leg
39271 JT Skew Bar 3" "Tuck"
39420 JT Spacer for Feed Belt Take-Up Assembly
39447 JT Stud Cover Mounting
39453 JT Slide for Spring Link Assembly
39454 JT Link
39482 JT Aligner take-up stud
39486 JT Guard, Belt, Green
39569 JT Bushing for top feed pinch wheel arms 3/4 I.D.
39583 JT Nip Bar 1st Unit
40219 JT Shield, Wind
40273 JT Washer, Flat, Nonmetallic
40286 JT Cover, Fountain, GS 1 Color SJ
40287 JT Cover, Fountain, GS 2 Color SJ
40417 JT Plunger
40694 JT Handle Water Pan
40695 JT Feed Arm Bushing
40752 JT Vacuum Hose
41038 JT Feed Arm Bushing
41183 JT Nut Plate
41197 JT Lower Pump Housing
41198 JT Water Motor Assy
41506 JT Cover, 2nd Unit
41521 JT Bracket, Hinge
41523 JT Cover 3" 2 Color GS Btwn Towers
41524 JT Bracket
41526 JT Cam, Interlock Cover Switch
41534 JT Bracket, Hinge

41536 JT Cover, Top
41556 JT Dog Plate 4-pin style
41566 JT Nut plate 4-pin style
41567 JT Dog Plate 4-pin style
41568 JT Flange Plate
41569 JT Harmonic Drive SJ
41570 JT Clamp for Harmonic Drive
41571 JT Cover rear
41676 JT Cover, CI Feeder
41679 JT Cover, Rear Dual Feed
41816 JT Connector
41827 JT Latch, Washup Pan
41867 JT Front Aligner Shaft
41868 JT Rear Aligner Shaft
41966 JT Arm Stripper Assembly Operator Side
41990 JT Shaft power drive
42202 JT Plate for Entrance Roller Brake
42204 JT Power Drive Shaft
42248 JT Plate for Entrance Roller Brake
42261 JT Hub
42298 JT Drive Motor 1 1/2HP 180VDC
42331 JT Elec Box Connector Panel
42402 JT Water Meter Valve
42558 JT Aligner Take-Up Arm
42592 JT Aligner Take-Up Arm
42593 JT
42594 JT Aligner Take-Up Arm
42610 JT Arm Imp Solenoid HWS
42659 JT K.O. Terminal #2
42660 JT K.O. Terminal Ftn. #1
42666 JT Spacer for Jet Press Harmonic Drive Key
42667 JT Key 3" Harmonic
42675 JT Stud for Adjustable Knock-off Assembly
42676 JT Container belt
42695 JT Stud for Adjustable Knock-off Assembly
42705 JT Ftn Cheek L.H.
42706 JT Ftn Cheek R.H.
42709 JT Block
42728 JT Spring for Wash Up Attachment O.S.
42729 JT Spring for Wash-up Attachment G.S.
42754 JT Plexiglass Cover SJ
42818 JT Spacer, Ring
43083 JT Plunger for Adjustable Knock-off Assembly
43085 JT Knock Off Assy. Cover
43085 JT Knock-off Cover
43410 JT Cable K.O. Assy Ftn. #1 Super Jet
43411 JT Form Wire Ftn. #1 Super Jet
43412 JT Cable K.O. Assy Ftn. #2 Super Jet
43413 JT Form Wire Ftn. #2 Super Jet
43417 JT Form Wire Ftn #1 Jet Press
43418 JT Cable K O Assy Ftn #1 Jet Press
43419 JT Form Wire Ftn. #2 Jet Press

43420 JT Cable K.O. Assy Ftn #2 Jet Press
43589 JT Gear, Spur, Shell Drive Plastic
43604 JT Roller, Shell Assy Gear Drive
43651 JT Guard, Chain Drive
43653 JT Guard, Chain Drive
43654 JT Guard, Chain Drive
43655 JT Guard, Chain Drive
43716 JT Pusher Gold
43717 JT Bracket, Mounting, Feeder Cover OP Side
43718 JT Bracket, Mounting, Feeder Cover GS Side
43720 JT Plate, Self Locking
43722 JT Nut Plate Hinge
43723 JT Pusher Gold
43724 JT Hinge, Cover Btm Feed
43725 JT Cam, Interlock Cover Switch
43736 JT Cam, Interlock Cover Switch
43737 JT Cover, Fountain 1 Feed End
43738 JT Block
43738 JT Block for Fountain
43773 JT Bushing
43930 JT Key
44141 JT Steel Wheel
44142 JT Steel Pinch Wheel
44169 JT Bracket, Mounting Spring
44170 JT Link plate
44249 JT Cover, Aligner Sideframe
44254 JT Cover, Gear Side
44256 JT Stud
44260 JT Spacer
44297 JT Dampener tray Stud Extension O.S.
44319 JT Nutr for Dampener Tie Rod Assembly
44320 JT Stud for Dampener Tie Rod Assembly
44321 JT Knurled Nut for Dampener Tie Rod Assembly
44322 JT Terminal for Dampener Tie Rod Assembly
44331 JT Tie Rod
44341 JT Pivot, Arm, entrance roller assy
44482 JT Sprocket
44484 JT Tension Post - Feed take-up
44485 JT Arm for Feed Chain Tensioner
44486 JT Collar for Feed Take-up Tensioner
44489 JT Feed Chain for Cast iron Feed
44514 JT Squeegee Clamp
44554 JT Spring O.S.
44555 JT Spring G.S.
44562 JT Screw, Cap SH
44696 JT Impeller 2 1/4 Dia
44771 JT Stud
44869 JT Feed Chain Cast Iron Feed - with 44482 Sprocket
44870 JT Pinch Wheel 3/4" Wide
44902 JT Nut Drive Belt Take-up Assy
46601 JT Key
46642 JT 2 Hole Pusher

46847 JT Nylon Plug for Knock off Asembly
46922 JT Power Drive Shaft Ig.
46963 JT Cover, Fountain GS 2 Color 3"
46973 JT Housing for Hand Wheel Asembly
46974 JT Power Drive Shaft Ig.
46991 JT Vacuum Hose -Short
47169 JT Screw for Spider Steel Wheel Conversion
47171 JT Arm - Short Front Spider Assembly O.S.
47172 JT Arm - Short Spider Assy Front G.S.
47173 JT Arm - Long Spider Assembly Rear O.S.
47174 JT Arm - Long Spider Assembly Rear G.S.
47180 JT Shaft - Pinch Roller
47181 JT Post, Belt Tension
47182 JT Arm, Adj Clamp
47188 JT Shaft for Bogie Wheels on Swing Away Feed
47189 JT Stud, Arm cam Follower see 30717
47201 JT Bar, Sucker Mounting
47203 JT Bar, Sucker Gear Side
47208 JT Support, Bogie Rollers
47326 JT Collar
47327 JT Bar Nip 6"
47328 JT Drive Flange 4-Pin Dog / Flange Combo
47330 JT Nut Plate
47571 JT Drive Flange 4-Pin Dog / Flange Combo
47574 JT Nut Plate
47605 JT Ductor Roller
48107 JT Spacer
48290 JT Ink Fountain blade WIDE
48340 JT Screw Cone Head for 3" P/C Shaft
48347 JT Roller Shaft Wide
48348 JT Ink Roller Wide
48350 JT Drive Motor Pulley
48352 JT Jet Press Plate Cylinder Shaft
48380 JT Shaft, Sucker
48451 JT Drive Motor Pulley
48456 JT Jet Press Plate Cylinder Shaft
48662 JT Key
48664 JT Cover Harmonic Drive
48805 JT Key
48806 JT Harmonic Drive
48830 JT Block, Jam Switch Hanger OP Side
48833 JT Cap See 30878 Hole On Left
48834 JT Sideplate, Main OP Side
49030 JT Cover, Harmonic Drive
49067 JT Bracket, Safety Switch Mount 3 & 6 in
49087 JT Bracket, Magnetic Latch
49089 JT Switch Assy Harmonic Drive Cover
49097 JT Knock Off Plate Clamp for Adjustable K.O.
49099 JT Shaft for Feed Cam -Dual Feed Press see 30723
49112 JT Worm Gear Set 50:1 ratio
49280 JT Knock Off Plate Clamp for Adjustable K.O.
49480 JT Clip

49544 JT Tie Bar, Ex-Feeder
49711 JT Document stop
49723 JT Cover after 1992
49725 JT Cover, Rear Dual Feed [aft 1992]
49725 JT Pin - Shaft for Lower Feed Drive Gear
49775 JT Cap See 30878 Hole On Left
49938 JT Arm Swing Away Feed
49992 JT Guard
50324 JT Impeller Housing Assy
50493 JT Bracket, Limit Switch
50586 JT Cover, Outboard Dr GS Top
50588 JT Cover, Limit Switch
50589 JT Pin - Shaft for Lower Feed Drive Gear
50590 JT Bracket, Mounting Switch
50591 JT Guard, Gear GS
50864 JT Cover, Gear Upper Feed 3-5-98
50908 JT Latch, Handle, Upper Feed
50909 JT Block, Latch, Upper Feed
50910 JT Block, Mounting, Upper Feed OP Side
50911 JT Block, Mounting, Upper Feed GS Side
51009 JT Nip Guard, Sucker Shell
51286 JT Cover, 1c SJ
51287 JT Plate, Back
51288 JT Cover, Fountain
51372 JT Support Stud for Lower Feed Arm - Large Style
51380 JT Lower Feed Arm with Bushing - Large Style
51429 JT Lower Feed Arm Stud "Large"
51485 JT Knob, Guide Adj
51488 JT Document stop
51508 JT Cam - cover assy
51542 JT Shaft, Shell Drive Gear Driven
51548 JT Pully, Groove, Shell Drive
51555 JT Nut, Self Locking Square
51557 JT Pin, Hollow
51558 JT Spacer, Ring
51563 JT Washer, Retainer
51624 JT Bracket Cam Switch
51660 JT Cover, Feed Cam
52415 JT Cover
52794 JT Cover, Feeder
53294 JT Cam, Interlock Cover Switch
53422 JT Bracket, Cover
53477 JT Spacer, Switch
53561 JT Cover, Actuator Arm
53672 JT Shield, Lower Feed
53713 JT Cover, Gear Shield, Aligner GS
53986 JT Cover 6" GS 2C Top
54027 JT Bracket, Mounting Btm Feed Cover
54028 JT Cover, Btm Feed
54035 JT Pully, Drive Motor
54088 JT Cover, Outboard Dr GS Top
54092 JT Cover, Gaer Upper Feed

54570 JT Cover ftn #1 Wide
54666 JT Bracket Oiler Pump
54669 JT Guide-Spring Steel 3" Press
54765 JT Motor Delivery table
75118 JT Drive Motor Pulley
100041 JT Guide-Spring Steel 3" Press
100091 JT Motor
100115 JT Motor, Water
100133 JT Drive Motor 1 1/2HP 180VDC
100133 JT D.C. Motor
100201 JT Switch, Sensitive Roller Lever
100204 JT Switch, Cross Roller Plunger
100210 JT Leaf Switch
100406 JT Circuit Breaker
100415 JT Circuit Breaker
100425 JT Fuse Holder
100754 JT 3 Pole Relay
100755 JT 2 Pole Relay
100756 JT Time Delay Relay
101197 JT Leaf Switch
101198 JT Straight Cable Connector
101236 JT Connector Body, Plug Electrical
101237 JT Insert, Electrical Connector
101831 JT Connector Male & Female
101900 JT Receptacle
102420 JT Lamp
102665 JT DC Motor Speed Control
102733 JT Speed Potentiometer
102747 JT Resistor
102757 JT Photo Electric Eye for imp
103071 JT Motor Elec Box
103224 JT Brush
103225 JT Spring
103227 JT Brush Holder
106001 JT Bearing
106001 JT Bearing - PREMIUM
106003 JT Bearing - IMPORT
106004 JT Bearing
106004 JT Bearing - PREMIUM
106006 JT Bearing - IMPORT
106006 JT Bearing - PREMIUM
106008 JT Bearing - IMPORT
106008 JT Bearing - PREMIUM
106009 JT Bearing - IMPORT
106009 JT Bearing - PREMIUM
106012 JT Bearing - IMPORT
106012 JT Bearing - PREMIUM
106013 JT Bearing - IMPORT
106013 JT Bearing - PREMIUM
106014 JT Bearing - IMPORT
106018 JT Bearing - PREMIUM
106019 JT Bearing - PREMIUM

106023 JT Bearing - PREMIUM
106024 JT Bearing / Pulley
106028 JT Bearing - PREMIUM
106036 JT Bearing - Premium
106037 JT Bearing - PREMIUM 6" P/C
106038 JT Bearing - PREMIUM for 3"P/C
106057 JT Bearing Water System
106061 JT Bearing
106066 JT Bearing
106067 JT Thrust Bearing
106074 JT Bearing, Vac Pump
106076 JT Thrust Washer
106104 JT Bearing
106194 JT Table Shaft Bearing
106215 JT Belt, Positive Drive
106228 JT Belt, Positive Drive
106234 JT Belt
106259 JT Belt 56 Teeth 3/4 width
106317 JT Table Drive Belt
106318 JT Bushing for Water Roller Gibs
106321 JT Bushing for Plate Bender SJ
106327 JT Bushing for Imp Adj Shaft and 6" Plate Bender
106330 JT Bushing for Lolly-pop
106337 JT Bushing feed belt take up C.I. Feed
106341 JT Bushing K.O. O.S.
106342 JT Bushing G.S K.O.
106346 JT Bushing Ftn. Roller
106349 JT Bushing, Sucker Bar
106350 JT Bushing Sucker Bar
106356 JT Bushing, Lower Feed Arm
106382 JT Bushing lower feed pinch wheel pivot arm
106383 JT Bushing, Bearing
106385 JT Bushing
106389 JT Hardened Jig Bushing
106448 JT Bushing
106463 JT Bushing, Water Gib
106606 JT Cam Follower
106634 JT Tie Rod End
106710 JT Sleeve, Rubber Coupling
106729 JT Woods Coupling Ink Ftn
106731 JT Hose Clamp
106737 JT Tyton Snapper Clamp
106738 JT Hose Clamp
106792 JT Collar, Shaft
106793 JT Collar
106794 JT Collar
106795 JT Collar
106796 JT Collar Shaft
106797 JT Collar, Shaft
106798 JT Collar
106801 JT Collar, Shaft
106821 JT Plug Small

106822 JT Plug Large
106826 JT Collar
106833 JT Tee, Knob
106862 JT Steel Knob for Ductor Stop
106863 JT Connecting Link for Feed Chains
106884 JT Clip, Spring, Chain
106885 JT Spacer, Roller Chain
106905 JT Offset Link for Pusher Chains
107042 JT Knob
107045 JT Knob Feed Guide - Steel
107049 JT Knob - Feed Guide - Steel
107051 JT Handle Interlock wash-up Short 3/8-16
107051 JT Handle Interlock wash-up long
107054 JT Screw, Panel Fastener [with standoff]
107055 JT Cover Lock Screws
107056 JT Knob
107089 JT Handle, Adjustable
107093 JT Guide clamp ratcheting
107097 JT Handle
107103 JT Guide Clamp Ratcheting or 7648/7649 support
107113 JT Handle
107140 JT Knob, Back Guide Assy
107141 JT Screw With Knob
107221 JT Seal
107222 JT Seal
107224 JT Foot, Rubber
107227 JT Seal, Lower Feed
107228 JT Seal - Lower Feed Old Style Lg
107241 JT Gromet
107261 JT Grommet, Rubber 3"
107401 JT Plunger Screw, Quick Release
107402 JT Plunger Screw
107503 JT Ball Nose Screw
107506 JT Pulley for Delivery Table - Shaft Side
107561 JT Pulley for Power Drive
107578 JT Pulley for Outboard Drive
107582 JT Pully Timing Belt Del Table
107617 JT Pully Timing Belt Del Table
107736 JT Fastener, Tube
107801 JT Float Filter Assy
107801 JT Fan, Front Vac
107802 JT Float Filter Insert
107806 JT Vane, Oill Pump
107811 JT Body Gasket
107813 JT Fan
107815 JT Fan Guard
107835 JT Gasket
107836 JT Jar
107837 JT Vacuum Gauge
107849 JT Vacuum Valve
107853 JT Rebuild Kit, Oil Pump
107873 JT Muffler

107884 JT Vacuum Paper Filter
107924 JT Vacuum Pump Oilless, Gast
107927 JT Vane, Oilless Pump
107931 JT Vac Fan Coupling Assy
107932 JT Fan Guard
107935 JT Rebuild Kit, Oilless Pump
107949 JT Elbow, Reducing
107985 JT Vacuum Valve Top to Btm Feed
107986 JT Vacuum Filter Paper
107986 JT Check Valve
108601 JT Collar Nut
108603 JT T Nut 5-16X18
108604 JT Clip- Tubing
109603 JT T-Nut
111001 JT Clip, Tubing
111007 JT Tubing Nylon
111008 JT Metering Unit
111010 JT Compression Sleeve
111011 JT Metering Unit
111013 JT Junction Bar
111014 JT Tubing Nylon
111017 JT Tubing
111019 JT Grease Fitting Straight
111020 JT Grease Fitting 45 Degree
111072 JT Grease Fitting
111073 JT Grease Fitting Straight
111074 JT Grease Fitting 45 Degree
111086 JT Rubber Coupling for Ink Motor
121001 JT Flange, Coupling, Ink mtr side
121002 JT Coupling, Rubber for Ink Motor
121003 JT Flange, Coupling, Ink Ftn side
144312 JT switch cover
151008 JT Metal Tape 2"X50 yds
166013 JT Switch
166015 JT Cover, Microswitch
166030 JT Switch Body, Limit
166035 JT Actuator Switch
166057 JT Switch, Roller Actuator
169114 JT Latch, Slide, Tab Style
1111012 JT Gear box delivery table
3191001 JT Speed Potentiometer
4101002 JT Cover, Microswitch
4101010 JT Bottom Feed Pinch Wheel "Rubber"
5011001 JT Gear box reducer 10:1
5011005 JT Roller, Btm Feed Delvin
5011006 JT Bottom Feed Pinch Wheel "Rubber"
5081257 JT Ink Ductor Cheek LH
5081258 JT Ink Ductor Cheek RH
5081455 JT 2 Holed Pushers
5085001 JT Roller Kit - 7 Rollers - Litho Roller - Soft
5091001 JT Pusher, Slotted
5091002 JT Pusher

JT 2 Holed Pushers
001.063.2038 JT Screw, Cap SH
001.063.2087 JT Screw, Cap SH
001.063.2100 JT Screw, Cap SH
001.063.2125 JT Screw, Cap SH
001.083.2087 JT Screw, Cap SH
001.083.2150 JT Screw, Cap SH
001.102.4050 JT Screw, Cap SH
001.102.4075 JT Screw, Cap SH
001.102.4100 JT Screw, Cap SH
001.102.4150 JT Screw, Cap SH
001.103.2038 JT Screw, Cap SH
001.103.2050 JT Screw, Cap SH
001.103.2062 JT Screw, Cap SH
001.103.2075 JT Screw, Cap SH
001.103.2087 JT Screw, Cap SH
001.252.0038 JT Screw, Cap SH
001.252.0050 JT Screw, Cap SH
001.252.0062 JT Screw, Cap SH
001.252.0075 JT Screw, Cap SH
001.252.0087 JT Screw, Cap SH
001.252.0100 JT Cap Screw SH
001.252.0125 JT Screw, Cap SH
001.252.0150 JT Screw, Cap SH
001.252.0175 JT Screw, Cap SH
001.252.0275 JT Screw, Cap SH
001.311.8050 JT Screw, Cap SH
001.311.8062 JT Screw, Cap SH
001.311.8075 JT Screw, Cap SH
001.311.8100 JT Screw, SHCS
001.311.8125 JT Screw, Cap SH
001.311.8150 JT Screw, Cap SH
001.311.8300 JT Screw, Cap SH
001.381.6075 JT Screw, Cap SH
001.381.6100 JT Screw, Cap SH
001.381.6125 JT Screw, Cap SH
001.381.6150 JT Screw, SHCS
001.381.6200 JT Screw, Cap SH
001.501.3075 JT Screw, Cap SH
002.044.0025 JT Screw, Button Head
002.063.2025 JT Screw, Button Head
002.083.2038 JT Screw, Button Head
002.102.4038 JT Screw, Button Head
002.103.2025 JT Screw, Button Head
002.103.2038 JT Screw, Button Head
002.252.0025 JT Screw, Button Head
002.252.0038 JT Screw, Button Head
002.252.0050 JT Screw, Button Head
002.252.0062 JT Screw, Button Head
003.252.0050 JT Screw Hex Head
003.311.8087 JT Screw Hex Head
003.311.8100 JT Screw Hex Head

003.352.0150	JT	Screw, Hex Head
004.044.0025	JT	Screw, Flat Head Socket
004.063.2038	JT	Screw, Flat Head Socket
004.083.2038	JT	Screw, Flat Head Socket
004.102.4038	JT	Screw, Flat Head Socket
004.102.4050	JT	Screw, Flat Head Socket
004.103.2050	JT	Screw, Flat Head Socket
004.252.0050	JT	Screw, Flat Head Socket
005.102.4000	JT	Nut, Hex
005.252.0000	JT	Nut, Hex
005.381.6000	JT	Nut, Hex
006.051.6002	JT	Nut, Castle
006.252.0000	JT	Nut, Jam
007.044.0025	JT	Screw, Binding Head
007.063.2012	JT	Screw, Binding Head
007.063.2025	JT	Screw, Binding Head
007.063.2100	JT	Screw, Binding Head
007.103.2038	JT	Screw, Binding Head
009.250.0500	JT	Screw, Shoulder
009.312.0380	JT	Shoulder bolt ink ftn lock down stripper support
009.312.0500	JT	Shoulder bolt 5/16 X 1/2 Plate cylinder assy
009.380.0500	JT	Shoulder Screw Ink Idler Roller
009.500.0500	JT	Shoulder Screw for Ductor Arms
011.093.0062	JT	Pin, Roll
011.125.0050	JT	Roll Pin
011.125.0075	JT	Roll Pin
011.125.0100	JT	Roll Pin
011.187.0050	JT	Roll Pin
011.187.0062	JT	Roll Pin
011.187.0075	JT	Roll Pin
011.187.0087	JT	Roll Pin
011.187.0125	JT	Roll Pin
011.250.0050	JT	Pin, Roll
011.250.0075	JT	Roll Pin
011.250.0100	JT	Pin, Roll
011.250.0125	JT	Pin, Roll
012.187.0075	JT	Pin, Grooved
012.187.0100	JT	Pin
013.187.0075	JT	Pin, Dowel
013.250.0100	JT	Pin, Dowel
015.063.2012	JT	Set Screw Cup Point
015.083.2012	JT	Set Screw Cup Point
015.083.2100	JT	Set Screw Cup Point
015.102.4018	JT	Set Screw Cup Point
015.103.2018	JT	Set Screw Cup Point
015.103.2025	JT	Set Screw Cup Point
015.103.2050	JT	Set Screw Cup Point
015.252.0018	JT	Set Screw Cup Point
015.252.0025	JT	Set Screw Cup Point
015.252.0038	JT	Set Screw Cup Point
015.252.0100	JT	Set Screw Cup Point
015.252.8125	JT	Set Screw Cup Point

015.311.8038	JT	Set Screw Cup Point
015.311.8050	JT	Set Screw Cup Point
016.252.0038	JT	Set Screw Cup Point
017.063.2012	JT	Set Screw Cone Point
017.063.2038	JT	Set Screw Cone Point
017.252.0025	JT	Set Screw Cone Point
019.063.2038	JT	Pusher Screw
019.083.2050	JT	Cap Screw LH
019.102.4050	JT	Screw, Cap SH
019.252.0087	JT	Screw, Cap SH
020.252.0000	JT	Nut, Nylock
021.010.2400	JT	Washer, Lock
021.025.0000	JT	Washer, Lock
021.031.2000	JT	Washer, Lock
021.038.0000	JT	Washer, Lock
021.101.2400	JT	Washer, Lock
022.005.4000	JT	Washer, Flat
022.010.2400	JT	Washer, Flat
022.012.0000	JT	Washer, Flat
022.025.0050	JT	Washer, Flat
022.025.0620	JT	Washer, Flat
022.025.0916	JT	Washer, Flat
022.031.0980	JT	Washer, Flat
022.031.0981	JT	Washer, Flat
022.050.0001	JT	Washer
025.187.0062	JT	Pin, Grooved
025.187.0175	JT	Pin, Grooved
025.250.0075	JT	Pin, Grooved
028.006.1014	JT	Pop Rivet
028.012.0018	JT	Pop Rivet
028.012.0038	JT	Rivet, Pop
028.018.0037	JT	Pop Rivet
033.109.2362	JT	Washer, Pusher
034.384.5138	JT	Spring for swing away transfer wheel take ups
034.385.5175	JT	Spring Extension
034.385.5300	JT	Spring for Impression Vertical O.S. Short
034.385.5450	JT	Spring Stripper Assy
034.385.8250	JT	Spring
034.385.8300	JT	Spring Impression Vertical G.S. Long
036.182.6043	JT	Spring for Jet Press Plate Cylinder
036.243.8075	JT	Spring for Water Metering Roller
036.303.8068	JT	Spring for Spring Link and 3" Perfect Anti-backlash Gear LC-038D6
036.363.8068	JT	Spring for K.O. Assembly
036.607.2175	JT	Spring, Compression
037.011.0604	JT	Spring for Entrance Roller Brake
037.011.0804	JT	Spring Ductor arms
037.011.1004	JT	Spring
037.021.0604	JT	Spring Super Jet Anti-backlash Gear
037.026.0604	JT	Spring Form Arms
037.111.1004	JT	Spring for Feed Pinch Wheels and Super Jet P / C
038.252.0062	JT	Set Screw Oval Point
040.025.5100	JT	Ring, Retaining Ext

040.025.5555	JT	Ring, Retaining Ext
040.037.5100	JT	Ring, Retaining Ext
040.040.5100	JT	Ring, Retaining Ext
040.050.5100	JT	Ring, Retaining Ext
040.062.5100	JT	Ring, Retaining Ext
040.062.5133	JT	Ring, Retaining, Ext
040.075.5100	JT	Ring, Retaining Ext
040.075.5555	JT	Ring, Retaining ext
040.087.5000	JT	Ring, Retaining int
040.100.5100	JT	Ring, Retaining ext
040.112.5000	JT	Ring, Retaining Ext
040.112.5100	JT	Ring, Retaining Ext
040.137.5000	JT	Ring, Retaining int
040.156.5000	JT	Ring, Retaining int
040.162.5000	JT	Ring, Retaining int
040.200.5000	JT	Ring, Retaining int
041.015.1100	JT	Ring, Retaining ext
041.035.0100	JT	Ring, Retaining int
043.181.8100	JT	Gib Key 3/16 X 3/16 X 1"
044.181.8100	JT	3/16 X 3X16 X 1 key
044.181.8150	JT	Gib Key 3/16 X 3/16 X 1-1/2"
058.075.0754	JT	Elbow, 45 Degree Galvanized
058.075.0759	JT	Elbow, 90 Degree Galvanized
060.022.0000	JT	MDL2 Fuse
063.075.0200	JT	Nipple, Galvanized
063.075.0300	JT	Nipple, Galvanized
070.102.4625	JT	Thumbscrew
070.103.2100	JT	Thumbscrew
074.311.8100	JT	Bolt, Grade 8
074.311.8125	JT	Bolt, Grade 8
091.003.0025	JT	Screw, Cap SH
091.004.0025	JT	Screw, Cap SH
091.005.0016	JT	Screw, Cap SH
091.006.0016	JT	Screw, Cap SH
091.006.0018	JT	Screw, Cap SH
091.006.0030	JT	Screw, Cap SH
091.006.0035	JT	Screw Cap, SH
091.008.0014	JT	Screw, Cap SH
091.008.0065	JT	Screw, SHCS
091.012.0045	JT	Screw, Cap SH
092.003.0006	JT	Screw, Button Head
093.006.0016	JT	Screw, Flat Head Socket
096.006.0006	JT	Set Screw Locking
096.006.0010	JT	Set Screw
096.006.0012	JT	Set Screw
097.005.0030	JT	Roll Pin
098.006.0118	JT	Washer, Lock
098.006.0126	JT	Washer, Flat
098.008.7980	JT	Washer, Lock
099.003.0007	JT	Washer, Flat
099.008.0002	JT	Washer, Flat
1652B	JT	Grease Fitting

41198CE JT Water Motor Assy S/N5370 up
5000-187 JT Snap Ring
5100-62 JT Waldes Retaining Ring
9-0503-56 JT Shoulder Screw
9-0604-11 JT Spring for Entrance Roller Brake
9-0604-21 JT Spring for Super Jet Anti-backlash Gear
9-0604-26 JT Spring for Form Arms
9-0604-56 JT Shoulder Screw
9-0605-11 JT Spring for Aligner Chain Take-up
9-0605-11 JT Spring for Aligner Chain take-up
9-0606-26 JT Spring 3" P/C Anti-backlash
9-0804-11 JT Spring for Ductor Arm and Water Brake
9-0804-56 JT Shoulder Screw for Ductor Arms
9-1004-11 JT Spring
A-11027 JT Guide - Front Guide Plate
A-11142 JT Sucker Bar Assy Top Feed Swing Away
A-11144 JT Feed Arm Assembly
A-11179 JT Back Guide Assembly Top Feed G.S.
A-11180 JT Back Guide Assembly Top Feed O.S.
A-15009 JT Guide Rail Assy, Upper Aligner Chain
A-15010 JT Guide Rail Assy, Upper Aligner Chain
A-15011 JT Aligner Hold Down Rail GS
A-15012 JT Aligner Hold Down Rail OS
A-15017 JT Lower Feed Roller Assy 6"
A-15031 JT Stripper Assembly
A-15033 JT Stripper Finger
A-15041 JT See A-44340 New Style
A-15042 JT See A-44340 New Style
A-15048 JT Ductor Roller Bracket
A-15049 JT Ductor Roller Bracket
A-16010 JT Top Feed Link Tube Assy
A-16017 JT Tie Rod Assy
A-19259 JT Link Tube Assy for Lower Feed
A-29275 JT Plate Bender 6"
A-22279 JT Exit Roller Assy - USED -
A-22279 JT Exit Roller Assy - NEW -
A-22280 JT Lower Entrance Roller Assy 3"
A-28524 JT Super Jet Plate Cylinder
A-29467 JT Fountain #2 Disconnect
A-29534 JT Sucker Bar Assy, Lower Feed
A-29535 JT Roller Assy 3in. Feed Btm Feed
A-29575 JT Sucker Assy
A-29588 JT Center Assy, Shift C
A-29628 JT Spider Hold Down Assembly for Rubber Transer Roller System
A-29634 JT Front Assy, Btm Feeder
A-29659 JT Lower Feed Arm With bushing and Cam Follower
A-29673 JT Guide Assy, Back
A-29720 JT Shaft Assy, Pinch Roller Btm Feed
A-29745 JT Hopper Assy, Btm Feed
A-29773 JT Weight Assy
A-29793 JT Guide Assy Lower Feed R.H. Side - Short
A-29794 JT Guide Assy Lower Feed L.H. - Long

A-29795 JT Leaf Assembly - Lower Feed Stock Transfer Hold Down
A-29796 JT Front Guide Assy - Lower Feeder
A-29800 JT Guide Assy Lower Feed L.H. Side - Long
A-29801 JT Guide Assy Lower Feed R.H. Side - Short
A-29832 JT Handle Assy, Clamp
A-29950 JT Hose Assy Ftn. #1
A-29951 JT Hose Assy Ftn #1
A-30526 JT Pivot Arm Assy OP Side
A-30527 JT Pivot Arm Assy Gear Side
A-3071017 JT Switch Assy Harmonic Drive Cover
A-30853 JT Air Valve Assembly for Top to Bottom Feed
A-30883 JT Gear Subassembly, Drive
A-30886 JT Hub Assy, Gear
A-30889 JT Hub Assy, Cam
A-30904 JT Plate Cylinder Shaft Assy 6"
A-30914 JT Arm Assy Top Feeder
A-30941 JT Sideplate Assy, Main LH
A-30945 JT Center Assy Shaft R
A-30948 JT Cam Assy, Gear Feed
A-30958 JT Roller Assy
A-31022 JT Brake Assy
A-31058 JT Ductor Stop
A-31139 JT Feed Chain for Swing Away Feed
A-31786 JT Plate Cylinder Shaft Assy Jet Press
A-32004 JT Plate Cylinder Shaft Assy 6"
A-33580 JT Screw for 30870 Pin Shaft
A-34540 JT Blanket Cylinder
A-34615 JT Sucker Bar Assy CI Feeder
A-34616 JT Sprocket Assembly
A-34619 JT Upper Guide Cast Iron Feed - Operator Side
A-34620 JT Upper Guide Cast Iron Feed - Gear Side
A-34621 JT Feed Pinch Roller Assy
A-34622 JT Arm Feed Assy LH
A-34623 JT Arm Feed Assy RH
A-34625 JT Feed Stack Support C.I. Feed
A-34630 JT Front Guide Assembly Top Feed
A-34634 JT Support Guide Top Feed G.S.
A-34635 JT Support Guide Top Feed O.S.
A-34649 JT Link Assembly
A-34653 JT Oil Line Assy
A-35135 JT Support Assy, Paper
A-35961 JT Impression Adjustment Assembly
A-35996 JT Link Assembly Gear Side
A-35997 JT Link Assembly Operator Side
A-36000 JT Arm and Cap
A-36234 JT Complete Blanket Cyl & Shaft Assy see print #48163
A-36909 JT Feed Guide Top Feed G.S.
A-36910 JT Feed Guide Top Feed O.S.
A-36996 JT See - A-42597
A-37815 JT Arm Dist / Cap Assy
A-37816 JT Arm Dist / Cap Assy
A-37818 JT Delivery Table Wheel Assemblies "Lolly-pop"

A-37819 JT Lolly-pop Assy
A-38355 JT Sprocket Assembly for Aligner Take-up Assy
A-38365 JT See - A-42596
A-38366 JT See - A-42597
A-38494 JT Delivery Table Wheel Assemblies "Lolly-pop"
A-38494 JT Lower Feed Arm with Bushing
A-38549 JT Top Feed Guide Assembly G.S.
A-38550 JT Top Feed Guide Assembly O.S.
A-38903 JT Anti Backlash Gear Assy SJ
A-39178 JT Water Tank Ball Valve Assembly
A-39452 JT Spring Link
A-39719 JT Lower Feed Arm with Bushing
A-40697 JT Idler Assy
A-40698 JT Roller Sub Assy
A-40699 JT G.S. Gib Assy
A-40700 JT O.S. Gib Assy
A-40701 JT Chrome Roller Assy
A-40702 JT Water Metering Roller Assy
A-40703 JT Motor Bracket Sub-Assy
A-41040 JT Hub Assy
A-41041 JT Latch Assy, OP Side
A-41042 JT Latch Assy, Gear Side
A-41944 JT Wash -up Assy. Ftn. \$2 Interlock Style w/ Short Handle
A-42317 JT Imp Anti Backlash Gear SJ
A-42596 JT Aligner Take-Up Assembly Gear Side
A-42597 JT Aligner Take-Up Assembly Operator Side
A-42697 JT 6" Anti-backlash Gear
A-42710 JT Fountain Cheek Assembly L.H.
A-42711 JT Fountain Cheek Assembly R.H.
A-42712 JT Ink Fountain Assy
A-42737 JT Cable Assy.
A-42750 JT Wash -up Assy. Ftn. #1 Interlock Style w/ Short Handle
A-42752 JT Rear Cover Kit 3 & 6 in
A-42755 JT Rear Cover Plate SJ
A-42756 JT Top Feed Rear Cover, Dual Feed
A-42757 JT Top Cover
A-42793 JT Switch Assy Side Cover
A-42828 JT Shaft Assy, Sucker Drive
A-43086 JT K.O. Assy Super Jet Ftn. #2
A-43093 JT Bracket Micro Switch Cover 3 ""
A-43367 JT Cover Assy, CI Feeder
A-43414 JT K.O. Assy Super Jet Ftn. #1
A-43415 JT K.O. Assy Jet Press Ftn. #2
A-43416 JT K.O. Assy Jet Press Ftn. #1
A-43731 JT Lower Feeder Plexiglass Cover
A-43752 JT Cover Unit 1
A-44172 JT Stud Assy, Ecentric
A-44259 JT Outboard Drive Kit - Dual Feed Press
A-44263 JT Take Up Assy, Power Drive
A-44323 JT Dampener Tie Rod Arm Assembly
A-44340 JT Upper Entrance Roller
A-44487 JT Feed Chain take-up Assembly O.S.

A-44488 JT Feed Chain take-up Assembly G.S.
A-44762 JT Tension Arm Assy Feed Take-up
A-4499 JT Pusher Chain -G.S.- ** Chain only you will need to re-use blocks
A-4500 JT Pusher Chain -O.S.- * Chain Only you will need to re-use blocks
A-4501 JT Aligner Guide Assy Wide
A-4502 JT Aligner Guide Assy Wide
A-4503 JT Guide Assy Aligner Chain Med GS
A-4504 JT Guide Assy Aligner Chain Med OP Side
A-4530 JT Harmonic Drive
A-4567 JT Ink Roller - Litho Roller- Hard
A-4567 JT Ink Roller - Litho Roll - Soft
A-4567 JT Ink Roller - Jomac
A-4567 JT Roller Kit - 7 Rollers - Litho Roller -Soft
A-4567 JT Roller Kit - 7 Rollers - Litho Roller -Hard
A-46946 JT Aligner Assy 3"
A-46967 JT Aligner Assy Dual Feed
A-47168 JT Aligner Assy 3 & 6" CI
A-47170 JT Hold Down - Spider Assembly
A-47235 JT Water Gib Sub Assy Gear Side
A-47236 JT Water Gib Sub Assy
A-47310 JT Spider Hold Down Assembly for Steel Transer Roller System
A-47325 JT Counter - three counting functions and steps table
A-47626 JT Vibrator Gear Box Assy.
A-47627 JT K.O. Hub Assembly
A-47630 JT Roller Assy
A-47648 JT Bogie Roller Assy
A-47650 JT Shaft Assy, Idler Roller
A-47898 JT Shaft Assy, Feed End
A-47957 JT Counter - three counting functions and steps table
A-47958 JT Counter - three counting functions and steps table
A-4803 JT Dual Solenoid Assy
A-4803 JT Double Pnumatic Solenoid Kit JT Exclusive
A-48040 JT Harmonic Drive 3"
A-4811 JT Vibrator Gear Box Assy.
A-4812 JT K.O. Hub Assembly
A-4814 JT 6" Plate Cylinder and Shaft Assy.
A-4816 JT Delivery Table Assembly 6' Two Belt
A-4820 JT Single Solenoid Assy
A-4820 JT Single Pnumatic Solenoid Assy JT Exclusive
A-48203 JT 3" Plate Cyl Assy
A48207 JT Cover Assy, Gear Drive
A-48446 JT Cover Assy 2nd Unit
A-4846 JT Adapter Assembly for Fountain Roller
A-4855 JT Bronze and Grey Eccentric
A-4857 JT Ink Form Arm Assy
A-48711 JT 6" Plate Cylinder and Shaft Assy.
A-48922 JT Delivery Table Assembly 6' Two Belt
A-48924 JT Delivery Table Assembly 8' Four Belt
A-4893 JT Double Solenoid Kit With Mounting Plate
A-4893 JT Double Pnumatic Solenoid Kit JT Exclusive
A-4899 JT Upper Entrance roller Assy.
A-48999 JT Outboard Drive Kit - Top Feed Press

A-49188J JT Roller Kit Jomac Roller
 A-49188L JT Roller Kit - Litho Roller - Soft
 A-49363 JT Impression Adjustment Handle
 A-49428 JT 3" Harmonic Drive Cover Assy
 A-49429 JT 6" Harmonic Drive Cover Assy
 A-49430 JT Impression Adjustment Assembly
 A-49501 JT Knob for Top Feed Document Stop
 A-49502 JT Fountain Cheek Assy
 A-49518 JT Tygon Tubing Coupling
 A-49717 JT Fountain Cheek Assy
 A-49718 JT Brush Assy HWS
 A-49910 JT Sideplate Assy, Main RH
 A-49919 JT Brush Assy OHWS
 A-49984 JT Pully Feed Belt Assy
 A-49989 JT Bogie Roller Assy
 A-5011006 JT Feed Roller Assembly 1/2" Wide
 A-5011007 JT Pinch Roller Assy Wide
 A-50181 JT Knob for Top Feed Document Stop
 A-50279 JT Feed Arm Assy. - Large
 A-50280 JT Arm/ Stud Assy lower feed arm upgrade
 A-50333 JT Hinge Assy 1c SJ
 A-50547 JT Cover Assy, Outboard Drive W/ btm feed
 A-5081593 JT Lolly-pop assy
 A-5081594 JT Cover- feed cam
 A-51242 JT Top Cover 1 Color SJ
 A-51252 JT Adapter Assy, Gear Idler
 A-51384 JT Feed Arm Assy. - Large
 A-51430 JT Arm/ Stud Assy lower feed arm upgrade
 A-51431 JT Lower Feeder Assy Complete
 A-51509 JT Feed Belt Take-up Assy. O.S.
 A-51552 JT Shaft Assy, Pinch Roller
 A-51553 JT Take Up Assy
 A-51591 JT Drive Assy, Shell Gear Driven
 A-51869 JT Sideplate Assy, Main OP Side
 A-51948 JT Cover Assy Feed Cam w/dual feed
 A-51949 JT Switch Assy Cam Follower Cover
 A-53016 JT Switch Assy, Gear Cover
 A-54029 JT Lower Feeder Cover Assy
 A-7008 JT Belt Feed Assy, CI Feeder
 A-7009 JT Feed Belt Take-up Assy. G.S.
 A-7010 JT Feed Belt Take-up Assy. O.S.
 A-7019 JT Spring Guide Assembly Top Feed Self Seal
 A-7055 JT Wash-up Assy Not for Interlocking System
 A-7062 JT Pinch Wheel Assy 1/2 Wide
 A-7062-W JT Pinch Wheel Assy 3/4" Wide
 A-7064 JT Feed Shell Assembly
 A-7066 JT Bogie Roller
 A-7153 JT Support Assy Feed End Gear Side
 A-7154 JT Support Assy Feed End OP Side
 B-7491 JT Oiler Brush
 LC-026B-4 JT Spring 3" P/C Skew Bar
 LC-038-C8 JT Spring Between Dampener Blocks

LC-038-D6 JT Spring for 3" Impression Anti-backlash gear
LC-038-E2 JT Spring for Upper Entrance Roller / K.O. Assy
LC-038-E5 JT Spring for K.O. Assy
LC-047-F4 JT Spring for Swing Feed Hold Down
LE-037-D9 JT Spring for Swing Feed Chain Take-up Assy.
LE-045-D4 JT Spring for Swing Away Feed Transfer Wheels
LE-055-D12 JT Spring for Stripper Assy.
LE-055-D4 JT Spring - Horizontal Impression
LE-058-D11 JT Spring for Impression Arm Vertical
LE-058-D9 JT Spring for Impression Arm Vertical
LOR-HJ-1-K JT Roller Kit - 7 Rollers - Litho Roller - Hard
LOR-HJ-1-K-2 JT Roller Kit - 7 Rollers - Litho Roller - Soft
MDL 2 JT MDL2 Fuse, Glass 5 pac